

Rinnai.


Control-R™

Connect for **smarter** hot water.

Control-R™ Wireless Module

Part #: RWM101

Control Your Rinnai Tankless Water Heater with the Touch of a Button



With Rinnai's Control-R™ Wireless Module, new and existing Rinnai Residential and Commercial Tankless Water Heaters (2006 and newer) can be remotely monitored and controlled via smart devices. Rinnai now has the capability to provide a new option for management, control and maintenance of Rinnai Tankless Water Heaters.

Control and Monitoring

Control the Rinnai Tankless Water Heater from a smart phone or tablet to turn the system on/off, change the water temperature and monitor status.

Remote Diagnostics and Maintenance

Gives technicians detailed system information via automatic alerts and remote diagnostic tools before ever leaving their place of business, leading to shorter maintenance and repair times.

Accessibility and Convenience

Get instant access to technical bulletins, product warranty, product registration, manuals, step-by-step repair guides and more!



For More Information:
Rinnai Customer Care **1-800-621-9419**

Dimensions (w, h, d)

Module: 3.69" x 3.69" x 1.18" (94 mm x 94 mm x 30 mm)
Shipping Carton: 6.125" x 2.88" x 6" (155.6 mm x 73 mm x 152.4 mm)

Weight

Module: 4.8 oz (0.14 kg) Shipping Carton: 6 oz (0.17 kg)

Features

- Works with all Rinnai Tankless Water Heater models manufactured 2006 and newer (except RH180 Hybrid Tank-Tankless Water Heaters).
The Lime Condition (LC) notification will not appear in the Rinnai mobile app when the Control-R™ Module is paired with the following series of Rinnai Tankless Water Heaters manufactured prior to 2009: VA, VB, KA and V53e.
- Attaches to side of water heater via magnetic enclosure (indoor models only) or mounts to an indoor wall with supplied mounting hardware.
- Pairs with only one Rinnai Tankless Water Heater.
- Included with purchase: Control-R™ Module with 5 feet (1.5 m) of wire for water heater connection; wall mounting hardware (2 anchors and 2 screws); and "Rinnai Control-R™ Wi-Fi Module Installation Manual."
- Title 24 Compliant - meets California Energy Commission's Title 24 requirements.

Installation Requirements

- Choose a central location inside the home or business where the Wi-Fi signal is strong. If the Rinnai Tankless Water Heater is located where the Wi-Fi signal is weak (such as basements or a mechanical room), the Control-R™ Module is designed so that wiring can run up to 300 feet (91 m) away from the water heater to ensure a strong Wi-Fi signal (18-22 gauge wire is required).
- The Control-R™ Module must be installed indoors.
- Adequate space must surround the Control-R™ Module for service and support needs.

Supported Devices

- Apple® devices (iPhone, iPad, etc.) running operating system 8.0 or higher.
- Android® devices (phones, tablets, etc.) running operating system 4.4 or higher.

BlackBerry® devices are not supported.

Compatibility

- 802.11N Wi-Fi Network up to 2.4 GHz.
- Not compatible with MC-195T-US or MC-100V controllers.


Security

- Wi-Fi and ZigBee* 128-Bit AES Encryption
* ZigBee is a wireless technology used for the Control-R™ Module and wireless demand recirculation accessories.

Control-R™ Wireless Module

Part Number: RWM101

HOW IT WORKS



The new Control-R™ Module attaches easily to the Rinnai Tankless Water Heater by a two-wire interface quickly connecting through your Wi-Fi network for monitoring. Once connected and the free Rinnai mobile app is downloaded, the Rinnai Tankless Water Heater can be controlled using your smart phone or tablet.

The Rinnai mobile app is available from the Apple® Store or Google® Play Store.



RECIRCULATION CAPABILITY

If your system has recirculation capability, you can activate recirculation through the use of the Control-R™ Module, motion sensor or push button for faster hot water.



Push Button

Part #: RWMPB01 Mounted near the point of use, like a kitchen faucet or bathroom sink, and operates the recirculation system.



Motion Sensor

Part #: RWMMS01 Mounted near the point of use and operates the recirculation system with the detection of motion and full-body movement up to 30 feet (9 m).



Temperature Sensor

Turns off the recirculation system when the water has reached the set temperature. Compatible only with Rinnai Tankless Water Heaters featuring Rinnai Circ-Logic™.

The Temperature Sensor is only sold as part of the following Demand Recirculation Kits: **RWMKT03** and **RWMKT03P** (shown in table below).

DEMAND RECIRCULATION KITS

SE+ Featuring ThermaCirc360™ Series (RUR Models)	HE+ Series (RL Models) and SE+ Series (RUC/RU Models)
<p>RWMKT01 Kit Contents:</p> <ul style="list-style-type: none"> • Control-R™ Module • Push Button Device 	<p>RWMKT01P Kit Contents:</p> <ul style="list-style-type: none"> • Control-R™ Module • Push Button Device • External Pump
<p>RWMKT03 Kit Contents:</p> <ul style="list-style-type: none"> • Control-R™ Module • Push Button Device • Temperature Sensor 	<p>RWMKT03P Kit Contents:</p> <ul style="list-style-type: none"> • Control-R™ Module • Push Button Device • Temperature Sensor • External Pump

Rinnai America Corporation • 103 International Drive, Peachtree City, GA 30269 • 1-800-621-9419 • rinnai.us

©2017 Rinnai America Corporation. Rinnai America Corporation continually updates materials, and as such, content is subject to change without notice. Local, state, provincial federal and national fuel gas codes must be adhered to prior to and upon installation.

RWM101-SP-1
3/2017